






## Best Practice Sheet for Armorgard PipeRack PR1

| <b>Best Practice for PipeRack PR1</b>                                                                                                                                       |                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| <p>1. The Working Load Limit (WLL) of the PipeRack PR1 is 1000kgs (static) WLL when mobile = 500Kgs</p> <p>Manoeuvring the unit must be done so using two people.</p>       |   |
| <p>2. Brakes <b>MUST</b> be applied whilst the PipeRack is being loaded.</p>                                                                                                |  |
| <p>3. Any material transported by this PipeRack <b>MUST</b> be evenly distributed ensuring heaviest weights are at the base in order to be classed as a 'SAFE' product.</p> |  |

